

## REVERSIBILITY

With this option the user can choose the polarity of its generator.

Two kinds of polarity reversibility are offered depending on the voltage:

- External Reversibility : up to 15 kV
- Internal Reversibility : from 16 kV to 50 kV
- 

For voltages higher than 50 kV, reversibility is not a standard option and special inquiry has to be requested.



### 1- External reversibility : Up to 15 kV

The machine is delivered with :

- 2 shielded connectors ( PLUS pole and MINUS pole ),
- one HV shielded cable and
- one terminator.

The polarity is choosed by plugging the terminator in the selected pole to fix the ground.

*Terminator is connected to minus pole.  
POSITIVE output voltage is available  
on HV cable.*



*Terminator is connected to PLUS pole.  
NEGATIVE output voltage is available  
on HV cable.*

2- Internal reversibility: from 16kV to 50 kV

For changing the polarity, user has to turn a removable block located in the chassis. The removable block can be reached easily by opening the top cover (6 screws has to be screwed-off).

This operation takes a few minutes.

